


Besser Vacuum - DIVA machine spare part list and exploded view

Code	Eng description	UM
AA00224	Complete welding bar Diva	pc
AA00348	Inner bar body 33	pc
AA00208	Upper gasket for external abs suction machine	pc
AA00209	Lower gasket for external abs suction machine	pc
AA00230	Purple adhesive lexan label Diva	pc
AA00206	White counterbar list 15x8	lm
AA00215	Abs ext. suction chamber cover with label	pc
AA00218	Microswitch	pc
AA00207	Microswitch without lever	pc
AA00488	Pump Diva 115V - 60Hz	pc
AA00231	Pump Diva 220V - 50Hz	pc
AA00214	Welding resistance 3x0,1	m
AA00229	Power electronic board with vacuum sensor Diva 220V	pc
AA00490	Power electronic board with vacuum sensor Diva 110V	pc
AA00228	White structure abs for Diva / Sprint	pc
AA00219	620 mbar gauge without pcb	pc
AA00073	Teflon tape s45	m
AA00223	20VA transformer for 220V machines	pc

Exploded View



REF. EXPL. VIEW	DESCRIPTION	QTY	M.O.Q.
1	STRUCTURE	1	PC
2	BASE	1	PC
3	LID	1	PC
4	ELECTRONIC BOARD	1	PC
5	ADHESIVE LEXAN	1	PC
6	PUMP	1	PC
7	MICROSWITCH	2	PC
8	TRANSFORMER	1	PC
9	LOWER GASKET	1	PC
10	UPPER GASKET	1	PC
11	WHITE RUBBER	1	MT
12	WELDING BAR SUPPORT	1	PC
13	RESISTENCE	1	MT
14	WELDING BAR TEFLON	1	MT
15	FOOT	4	PCS