



SN	Name	Q'ty	SN	Name	Q'ty
1	Top cover	1	24	Transmission shaft Adjusting board B	1
2	Big Pulley A	1	25	Control plate	1
3	Nut M16	5	26	Relay	1
4	Tower Pulley B	1	27	Start button	1
5	V belt	6	28	Emergency stop switch	1
6	Bearing 6004	3	29	Small pulley	1
7	Bearing block	1	30	Casters	2
8	Bearing 6005	2	31	Casters with stopper	2
9	Oil seal	1	32	V belt	2
10	Bolts	2	33	Big pulley B	1
11	block	2	34	Bearing 6004	1
12	body	1	35	Bearing block(for bowl)	1
13	Mirco switch	1	36	Bearing 6205	1
14	Mirco switch support	1	37	Transmission plate	1
15	Adjusting board	1	38	Bowl	1
16	Tower Pulley A	1	39	Lid (safety guard)	1
17	Small pulley	1	40	Mixing blade	1
18	Bearing UCFL205	2	41	Hook	1
19	Transmission shaft Adjusting board A	1	42	Mixershaft	1
20	Motor	1	43	Knob	3
21	Transmission shaft	1			
22	Back cover	1			
23	Bearing UCFL205	1			