



SN	Name	Q'ty	SN	Name	Q'ty
1	Mixershaft	1	30	(adjusting board)	1
2	Hook	1	31	knob	1
3	Mixing blade	1	32	Bearing 6205	1
4	Lid (safety guard)	1	33	(bearing block (for mixer shaft)	1
5	Bowl	1	34	Oil seal	1
6	transmission plate	1	35	Screws	2
7	Bearing 6207	1	36	Bolts	1
8	bearing block (for bowl)	1	37	Support for supporting lid	1
9	Bearing 6206	2	38	Microswitch	1
10	Top cover	1	39	Block	2
11	Nut M16	1	40	Body	1
12	Nut M10	2	41	Bolts	1
13	Tension gear Support Upper	1	42	Bearing UFCA206	2
14	Drive chain Upper	1	43	Transmission shaft	1
15	Big Chain wheel (for Transmission shaft	1	44	Motor	1
16	V belt A34	2	45	Back cover	1
17	Axle for tension gear	2	46	Control plate	1
18	Ring 28#	2	47	Timer	1
19	Bearing 6001	2	48	Start button	2
20	Tension gear	2	49	Speed change -over switch	2
21	Small chain wheel (for mixershaft)	2	50	Emergency switch	2
22	Ring11#	1	51	Small chain wheel (for transmission shaft)	1
23	V belt B39	2	52	Casters	2
24	Bearing 6005	1	53	Tension gear support A Lower	1
25	Big Pulley	1	54	Tension gear support B Lower	1
26	Pulley	1	55	big chain wheel (for bowl)	1
27	Pulley	1	56	Nuts M24	1
28	Bearing 6006	1	57	Casters with stopper	2
29	Bush	1	58	Driven Chain Lower	1