


SPARE PARTS



RIF N.°	DESCRIPTION	PLUS XL 4 226766
1/A	Door Handle	5M200030
1/B	Small lateral door handles	-
2/A	Door supporting plate (right)	-
2/B	Door supporting plate (left)	-
3	Washer	-
4	Door	4P050016

5	Door Glass	5V010016
6	Door glass gasket	5G100002
7	Counterdoor	4C020016
8	Door Frame	4T020016
9	Plate fixing screws	-
10	Plate fixing screws	4F020003
11/A	Control panel frame	4M020001
11/B	Control panel label	5E200400
12	Insulating material	5L010001
13	Left covering panel	4P040007
14	Top covering panel	4C030007
15	Back covering panel	4S030202
16	Right covering panel	4P040003
17	Bottom covering pannel	4B030002
18	Jacket	4I020003
19	Cooking chamber	7C010103
20	Chimney	4C030001
24	Heating elements supporting frame	4T060065
25	Lamp holder	5P110003
26	Lamp glass	5V010003
27	Lamp	5L020005
28	Fan	-
29	Circuit brakers board	-
30	Thermostat	5T010010
31	Thermostat knob	5M200003
32	Timer	-
33	Timer knob	-
34	Thermometer	5T010200
35	Heating element's warning light	5L020017
36	Heating element's switch	5I100016
37	Chamber light switch	5I100017
38	Heating element	5R050401
39	Refractory stone	5P050040
41	Terminal box	5M100001
42	Electrical main switch	-