


# SPARE PARTS



		<b>BASIC 2/40</b>
<b>RIF N.°</b>	<b>DESCRIPTION</b>	<b>226872</b>
1/A	Door Handle	5M200020
1/B	Small lateral door handles	
2/A	Door supporting plate (right)	4P100041
2/B	Door supporting plate (left)	4P100031
3	Washer	-
4	Door	4P050046
5	Door Glass	-
6	Door glass gasket	-

7	Counterdoor	4C020046
8	Door Frame	4T020047
9	Plate fixing screws	5V500017
10	Plate fixing screws	-
11/A	Control panel frame	-
11/B	Control panel label	5E204580
12	Insulating material	5L010001
13	Left covering panel	-
14	Top covering panel	4S030090
15	Back covering panel	-
16	Right covering panel	-
17	Bottom covering pannel	4S030095
18	Jacket	-
19	Cooking chamber	7C010145
20	Chimney	-
24	Heating elements supporting frame	6T400500
25	Lamp holder	-
26	Lamp glass	-
27	Lamp	-
28	Fan	-
29	Circuit brakers board	-
30	Thermostat	5T010005
31	Thermostat knob	5M200006
32	Timer	5T010300
33	Timer knob	5M200005
34	Thermometer	-
35	Heating element's warning light	5L020017
36	Heating element's switch	-
37	Chamber light switch	-
38	Heating element	5R050090
39	Refractory stone	5P050100
41	Terminal box	5M100005
42	Electrical main switch	5I100010