


SPARE PARTS



RIF N.°	DESCRIPTION	BASIC XL 99 227053
1/A	Door Handle	7M010007
1/B	Small lateral door handles	5M200016
2/A	Door supporting plate (right)	4P100007
2/B	Door supporting plate (left)	
3	Washer	3R030001
4	Door	4P050018

5	Door Glass	5V010015
6	Door glass gasket	5G100001
7	Counterdoor	4C020028
8	Door Frame	4T020005
9	Plate fixing screws	5V500019
10	Plate fixing screws	4F020028
11/A	Control panel frame	4M020002
11/B	Control panel label	5E204401
12	Insulating material	5L010001
13	Left covering panel	4P040037
14	Top covering panel	4C030013
15	Back covering panel	4S030209
16	Right covering panel	4P040032
17	Bottom covering pannel	4B030011
18	Jacket	4I020017
19	Cooking chamber	7C010112
20	Chimney	4C030005
24	Heating elements supporting frame	4T060070
25	Lamp holder	5P110003
26	Lamp glass	5V010003
27	Lamp	5L020005
28	Fan	-
29	Circuit brakers board	5S010050
30	Thermostat	5T010001
31	Thermostat knob	5M200003
32	Timer	-
33	Timer knob	-
34	Thermometer	5T010200
35	Heating element's warning light	5L020017
36	Heating element's switch	5I100011
37	Chamber light switch	5I100017
38	Heating element	5R050420
39	Refractory stone	5P050050
41	Terminal box	5M100001
42	Electrical main switch	-