


# SPARE PARTS



		<b>BASIC 2/50 GLASS</b>
<b>RIF N.°</b>	<b>DESCRIPTION</b>	<b>220733</b>
1/A	Door Handle	5M200020
1/B	Small lateral door handles	
2/A	Door supporting plate (right)	4P100018
2/B	Door supporting plate (left)	4P100017
3	Washer	-
4	Door	4P050051
5	Door Glass	5V010015
6	Door glass gasket	5G100001

7	Counterdoor	4C020051
8	Door Frame	4T020055
9	Plate fixing screws	5V500017
10	Plate fixing screws	4F020100
11/A	Control panel frame	4M010200
11/B	Control panel label	5E204570
12	Insulating material	5L010001
13	Left covering panel	4P040100
14	Top covering panel	4S030100
15	Back covering panel	-
16	Right covering panel	4P040105
17	Bottom covering pannel	-
18	Jacket	4I020050
19	Cooking chamber	7C010150
20	Chimney	-
24	Heating elements supporting frame	6T400108
25	Lamp holder	-
26	Lamp glass	-
27	Lamp	-
28	Fan	-
29	Circuit brakers board	-
30	Thermostat	5T010001
31	Thermostat knob	5M200003
32	Timer	-
33	Timer knob	-
34	Thermometer	-
35	Heating element's warning light	5L020017
36	Heating element's switch	5I100003
37	Chamber light switch	-
38	Heating element	5R050120
39	Refractory stone	5P050030
41	Terminal box	5M100001
42	Electrical main switch	-