

300L Spare parts list

No	Part name	QTY	PART CODE
2	LED light	1	1.01.03.03.072R
	door (inclu gasket)	1	3.1.06.2.1.1883
3	basket	1	1.05.08.10.041
4	hinge	2	1.05.06.07.004
5	upper cover	2	1.25.02.15.01.009
6	bottom cover	2	
9-17	compressor & accessories	1	1.01.01.01.416
26	compressor support	1	3.5.2.01.0039
28	castor	2	1.02.08.04.004
29	compressor cover	1	3.1.02.16.062
34	filter	1	1.03.30.03.013
37	power cord	1	1.01.01.01.827R
38	thermostat	1	1.03.02.01.016
39	Control panel	1	1.02.15.04.066
42	Control panel cover	1	1.02.15.04. 067
40	Control knob	1	1.02.15.06.048
27	front foot	2	1.02.08.04.004
49	handle cover	6	1.25.02.05.01.193
51	Door handle seat	2	1.25.02.05.01.088
41	Digital Display	1	1.01.07.04.005

BD192JA/BD282JA
(Exploder drawing)

