



1	Top cover		1
2	Handle frame end cap		4
3	Handle frame		1
4	O Ring		1
5	Handle sleeve		1
6	Top insulation assy		1
7	Top heater 230V/750W		1
8	Baking plate		1
9	Bottom heater 230V/750W		1
10	Bottom insulation assy		1
12	Knob insert(spring)		1
13	Knob		1
14	Knob scale plate		1
16	Thermostat 300°C		1
17	Heating indicator		1
18	Housing assy		1
19	Crumb tray		1
20	Terminal block		1
21	Power sheath	912201	1
22	Power cord with UL plug		1
23	Wire guide tube		1
24	Hi-limit 140°C		1
25	Reset stick location tube		1
26	Reset stick		1
27	Reset stick bracket		1
28	Bottom plate		1
29	Rubber foot		4
30	Fork sleeve		1
31	Fork		1