



TECNOSTEEL


ESPLOSO CUCINA FREE STANDING FIVECHEF / FIVEPLUS


EXPLODED VIEW OF FREE STANDING COOKER FIVECHEF / FIVEPLUS





























FIVECHEF (FC) / FIVEPLUS (FP)

FC965G - FC965MF / FP965G - FP965MF

n°	ARTICLE	DESCRIPTION	PRICE
01	009600714	Enameled wire pan support for lateral burners FC/FP	*
	009600730	Chromed wire pan support for lateral burners FC/FP	€ 14,00
02	009600715	Enameled wire pan support for central burners FC/FP	*
	009600731	Chromed wire pan support for central burners FC/FP	€ 15,00
03	009600716	Cast iron pan support for lateral burners FC/FP	*
04	009600717	Cast iron pan support for central burners FC/FP	*
05	009620715	Diamond-cut burner body for Triple 4KW FP	€ 6,00
06(=50)	012837009	External burner lid for Dual 5KW FC / Triple 4KW FP	€ 4,00
07(=51)	012837010	Inner burner lid for Dual 5KW FC / Triple 4KW FP	€ 1,00
08	009620714	Burner cup for Triple 4KW FP	€ 8,50
12	009620719	Complete Triple 4KW FP (no Thermocouple, no spark plug)	€ 19,50
13	009620712	Diamond-cut burner body for R 3KW FP	€ 2,50
14	009620713	Burner lid for R 3KW FP	€ 1,50
15	009620711	Burner cup for R 3KW FP	€ 2,00
19	009620718	Complete R 3KW FP (no Thermocouple, no spark plug)	€ 6,00
20	009620709	Diamond-cut burner body for SR 2KW FP	€ 1,50
21	009620710	Burner lid for SR 2KW FP	€ 1,50
22	009620708	Burner cup for SR 2KW FP	€ 1,50
26	009620717	Complete SR 2KW FP (no Thermocouple, no spark plug)	€ 4,50
27	009620706	Diamond-cut burner body for AUX 1KW FP	€ 1,00
28	009620707	Burner lid for AUX 1KW FP	€ 1,00
29	009620705	Burner cup for AUX 1KW FP	€ 1,50
33	009620716	Complete AUX 1KW FP (no Thermocouple, no spark plug)	€ 3,50
34	009620503	Stainless steel hob for FP cookers (only hob)	**
35	009610702	Diamond-cut burner body for CHEF SR 2,5KW FC	€ 4,00
36	009610703	Burner lid for CHEF SR 2,5KW FC	€ 4,50
37	009610701	Burner cup for CHEF SR 2,5KW FC	€ 7,50
41	012837025	Diamond-cut burner body for CHEF R 3,5KW FC	€ 6,50
42	012837026	Burner lid for CHEF R 3,5KW FC	€ 6,00
43	012837024	Burner cup for CHEF R 3,5KW FC	€ 9,50
47	009610704	Complete CHEF SR 2,5KW FC (no Thermocouple, no spark plug)	€ 16,00
48	012837042	Complete CHEF R 3,5KW FC (no Thermocouple, no spark plug)	€ 22,00
49	012837008	Diamond-cut burner body for Dual 5KW FC	€ 6,50
50	012837009	External burner lid for Dual 5KW FC / Triple 4KW FP	€ 4,00
51	012837010	Inner burner lid for Dual 5KW FC / Triple 4KW FP	€ 1,00
52	012837007	Burner cup for Dual 5KW FC	€ 17,00
59	012837041	Complete Dual 5KW FC (no Thermocouple, no spark plug)	€ 28,50
60	012837011	Spark plug for Dual 5KW FC	€ 3,00
61	012837014	Thermocouple for Dual 5KW FC	€ 4,00
62	012837027	Thermocouple for CHEF SR 2,5KW and CHEF R 3,5KW FC	€ 4,00
63	012837028	Spark plug for CHEF SR 2,5KW and CHEF R 3,5KW FC	€ 1,50

64	009620701	Spark plug for R 3KW, SR 2KW and AUX 1KW FP	€ 1,50
65	009620703	Thermocouple for R 3KW, SR 2KW and AUX 1KW FP	€ 4,00
66	009600712	Knob for gas tap FC/FP	€ 3,50
67	009600713	Knob for electric controls FC/FP	€ 3,50
68	009600506	Right side panel for FC/FP	€ 25,00
69	009600507	Left side panel for FC/FP	€ 25,00
70	009610705	Gas tap for FC (alluminium)***	€ 8,00
	009610706	Gas tap for FC (since April 2016)	€ 8,00
71	009620720	Gas tap for FP (alluminium)***	€ 8,00
	009620721	Gas tap for FP (since April 2016)	€ 8,00
72	009610503	Stainless steel hob for FC cookers (only hob)	**
73	009601703	Burner for gas oven FC/FP (compl. With TC and spark plug)	€ 20,00
76	009601704	Nozzle holder for gas oven FC/FP	€ 5,00
77	018237007	MTS57 timer (120') (for electric oven FC/FP)	€ 15,00
78	009601710	MTS57B timer (60') (for gas oven FC/FP)	€ 15,00
79	009601708	On/Off switch of light for gas oven FC/FP	€ 2,00
80	018237006	Green indicator light	€ 0,75
81	018237005	Orange indicator light	€ 0,75
82	009600718	Complete oven door (with handle and hinges) FC/FP	€ 85,00
83	009600706	Inner clear glass FC/FP	€ 18,00
84	009600709	Oven door handle FC/FP	€ 18,50
85	009600707	Oven door hinge FC/FP	€ 7,00
86	012807032	Stainless steel foot, adjustable in height, for cookers	€ 4,00
87	009601707	Oven door seal for gas oven FC/FP (3 sides)	€ 4,50
88	009602707	Oven door seal for electric oven FC/FP (4 sides)	€ 6,50
89	009600710	Seal for control panel FC/FP (1 side)	€ 2,50
90	009600708	Support with roller for hinges FC/FP	€ 5,00
91	018237009	Power cable	€ 4,00
92	018237008	Terminal box	€ 3,50
93	009600704	Complete light socket FC/FP	€ 4,00
94	018237001	3000W Round heating element	€ 15,00
95	009602704	1600W Bottom heating element MAXI FC/FP	€ 18,50
96	009602705	1000+2000W Ceiling + grill heating element MAXI FC/FP	€ 25,50
97	018237012	Complete fan motor	€ 20,00
98	002327010	9 pos +0 switch	€ 25,00
99	018237002	1 Bulb thermostat (0-270°C)	€ 15,00
100	009600702	Right grid/tray holder FC/FP	€ 9,00
101	009600703	Left grig/tray holder FC/FP	€ 9,00
102	009600701	Oven grid FC/FP	€ 12,00
103	009600503	Enameled oven tray FC/FP	€ 17,00
104	009600508	Rear panel FC/FP	**
105	012837001	Ignition box (6 exits)	€ 6,50
106	009601702	Gas ramp for cookers with gas oven FC/FP	€ 18,50
107	009602703	Gas ramp for cookers with electric oven FC/FP	€ 18,50
109	009601706	Insulating cover coat for gas oven FC/FP	€ 8,00
	009602706	Insulating cover coat for electric oven FC/FP	€ 10,50
110	009601506	Enameled cover for burner of gas oven FC/FP	€ 14,00
111	009600512	Enameled fan cover FC/FP	€ 15,00
112	009601709	On/Off switch of fan for gas oven FC/FP	€ 2,00
113	009601705	Thermostat-tap for gas oven FC/FP	€ 22,00

114	009600509	Cooker base FC/FP		**
115	009620702	Spark plug for Triple 4KW FP	€	3,00
116	009620704	Thermocouple for Triple 4KW FP	€	4,00
117	009600719	Micro-switch chain for 5 burners FC/FP (for aluminium gas taps)***	€	5,00
	009600711	Micro-switch chain for 5 burners FC/FP (since April 2016)	€	5,00

*****THIS IS A DRAFT VERSION*****

*** = Discontinued**

**** = Only on request**

***** = While stocks last**