





HENDI COOKERS: GAS AND ELECTRIC

n°	ARTICLE	DESCRIPTION	PRICE
01	012817010	Cast iron pan support	€ 25,00
02	012817008	Thermocouple 600mm	€ 4,00
03	012817002	3,5 KW Burner Lid	€ 11,50
04	012817001	3,5 KW Burner Body	€ 10,00
05	012817003	3,5 KW Venturi mixing tube	€ 4,50
06	012817005	6 KW Burner Lid	€ 13,00
07	012817004	6 KW Burner Body	€ 11,50
08	012817006	6 KW Venturi mixing tube	€ 5,50
09	012817013	Nozzle Ø 1,40 for 3,5KW (Methane - Europe)	€ 0,50
	012817014	Nozzle Ø 1,85 for 6KW (Methane - Europe)	€ 0,50
	012817015	Nozzle Ø 0,92 for 3,5KW (30MBAR LPG - Europe, no DE,AT,CH)	€ 0,50
	012817016	Nozzle Ø 1,20 for 6KW (30MBAR LPG - Europe, no DE,AT,CH)	€ 0,50
	012817017	Nozzle Ø 0,80 for 3,5KW (50MBAR LPG - DE, AT, CH)	€ 0,50
	012817018	Nozzle Ø 1,05 for 6KW (50MBAR LPG - DE, AT, CH)	€ 0,50
	012817019	Nozzle Ø 1,30 for 3,5KW (Methane - DE L + HU)	€ 0,50
	012817020	Nozzle Ø 1,70 for 6KW (Methane DE L + HU)	€ 0,50
	012817021	Nozzle Ø 1,45 for 3,5KW (G25 Methane - The Netherlands)	€ 0,50
	012817022	Nozzle Ø 1,90 for 6KW (G25 Methane - The Netherlands)	€ 0,50
10	012817009	Nozzle holder	€ 5,50
11	012817035	Gas tap for 3,5KW (since May 2016)	€ 8,00
12	012817036	Gas tap for 6KW (since May 2016)	€ 8,00
14	012807081	Black knob for gas tap with grey label (since May 2016)	€ 3,50
16	012817042	Spark Plug for cast iron burners (600mm) (only for electric ignition!)	€ 3,50
17	012837002	Ignition box (4 exits) (only for electric ignition!)	€ 6,00
18	012837001	Ignition box (6 exits) (only for electric ignition!)	€ 6,50
19	012837036	Micro-switch chain for 4 burners	€ 6,50
20	012837038	Micro-switch chain for 6 burners	€ 6,50
21	012867003	3,5 KW Chromed Burner Body	€ 10,00
22	012817038	3,5 KW Chromed Burner Lid	€ 11,50
23	012867004	6 KW Chromed Burner Body	€ 11,50
24	012817040	6 KW Chromed Burner Lid	€ 13,00
25	012807717	Grey knob for gas tap with grey label	€ 3,50
26	012807719	Grey knob for el. thermostat with grey label	€ 3,50
27	012807727	Grey knob for timer with grey label	€ 3,50
43	012827006	Cast iron hotplate, Ø220mm, 2600W, 230V	€ 25,00
44	012827007	7-position switch for hotplates, 16A, 250V	€ 9,00
45	012827004	Power cable for Electric cookers and tops	€ 6,50
46	012827003	Terminal box for Electric cookers and tops	€ 5,00
48	012807085	Black knob for hotplates with grey label (since May 2016)	€ 3,50
50	012807035	Support with roller for hinges	€ 5,00
51	012807033	Right oven door hinge	€ 7,00

52	012807034	Left oven door hinge	€	7,00
53	012807025	GN1/1 Oven grid	€	7,50
54	012807026	Right grid/tray holder for GN1/1 oven	€	9,00
55	012807027	Left grid/tray holder for GN1/1 oven	€	9,00
56	012805001	Fixing screw for grid/tray holders	€	1,50
57	012807028	Oven door seal for GN1/1 oven	€	8,00
58	012807036	Oven door handle	€	16,50
59	012805029	Complete Oven door (with handle and hinges)	€	85,00
60	018237011	Equipotential earthing terminal	€	2,00
61	018237009	Power cable for gas cookers and tops	€	4,00
62	018237008	Terminal box for gas cookers and tops	€	3,50
63	012807032	Stainless steel foot, adjustable in height, for cookers	€	4,00
64	002307007	Stainless steel foot, adjustable in height, for Tops	€	2,50
65	018237001	3000W Round heating element	€	15,00
66	018237012	Complete fan motor with fan for electric ovens	€	20,00
67	018237004	M6 Fan fixing nut	€	0,50
68	018237003	Stainless steel fan, 7 blades	€	5,50
69	018237014	Guard disk for fan motor insulation	€	2,00
70	018237005	Orange indicator light	€	0,75
71	018237006	Green indicator light	€	0,75
72	018237002	1 bulb thermostat (0-270°C)	€	15,00
73	018237007	MTS57 timer (120')	€	15,00
75	012807083	Black knob for el. thermostat with grey label (since May 2016)	€	3,50
78	012807082	Black knob for timer with grey label (since May 2016)	€	3,50
80	012807109	Burner for GN1/1 gas oven (complete with TC and spark plug)	€	20,00
81	012807101	Nozzle holder for gas oven	€	5,00
82	012817023	Nozzle Ø 1,60 for gas oven (Methane - all Europe)	€	0,50
	012817024	Nozzle Ø 1,02 for gas oven (LPG - all Europe)	€	0,50
83	012807105	Ignition box for GN1/1 gas oven (2 exits)	€	5,50
85	012807111	1-way thermostat for GN1/1 gas oven	€	18,00
88	012807064	Black knob for gas oven complete with adapter and grey label	€	3,50

Piano Gas / Gas Hob



12
6KW



09



10



03



04



05



11
3,5KW




14
Grey


Piano EVO / EVO Hob



16



17 4 EXITS



18 6 EXITS



19 4 BURNERS

20 6 BURNERS

23



21

24



22



25



26




27

Piano Piastre Elettriche / Electric Hotplate Hob


43




44



45



46



48
Grey

Accessori / Accessories




Forno Elettrico / Electric Oven

65



66



67

68

69


70 orange



71 green



72



73





75
Grey




78
Grey



Forno Gas / Gas Oven



83 2 EXITS



85
1-Way



88
Grey