

Catalog MX1500XTPSEK

Model

MX1500XT22CK (on units after 6/26/2008)

MX1500XT22SEK



Fax 860-496-9017 www.waringcommercialproducts.com

		www.waringcommercialproducts.com	
Illustration#	Part#	Description	
1	028769-E	Jar Lid Cover (changed after 10/8/2010)	
2	028768	Jar Lid	
3	503439 030888 503348	48 oz Raptor Container with Blending Assembly (changed after 2/28/2014) 48 oz. Stackale Container ONLY Container with Blending Assembly (use 503439)	
4	503601 503604 028538	Sq. Drive Coupling with Adapter (on units after 3/29/2022) Sq. Drive Coupling with Adapter 2 Gen. (changed after 1/7/2021) Drive Coupling	
5	026443	Jar Pad	
6	035399 028824	Leili Motor with Sensor (on units after 8/18/2017) ECM Motor with Sensor	
7	038278 026437	Dampening Plate Gasket (on units after 8/25/2022) Dampening Plate Gasket	
8	503382-K-67 503382-K	MX Housings, Ferrite Core & Cord (on units after 10/19/2017) MX Housings, Ferrite Core & Cord (on units after 4/27/2009)	
9	028541	Motor Foam (2 required)	
10	026439	Dampening Plate Bushing (4 required)	
11	038486 026453	Dampening Plate Sleeve (4 required on units after 8/25/2022) Dampening Plate Sleeve (4 required)	
12	026459	Washer (2 required)	
13	028929	Sems (4 required)	
14	035710	Control Panel with Interlock (changed after 8/18/2017) comes with key board-main board-filter board	
	029816	Soft Start Control Panel (use 035710)	
15	028248	Top Housing Foam Rear Baffle	
16	028249	Top Housing Foam Front Baffle	
17	Motor Housi	ng is Included with Illustration# 8	
18	002943	Washer (3 required)	
19	028247	Bottom Housing Foam Baffle	
20	028542	Foam Baffle	
21	034900	PCB Cushion (4 required on units after 7/18/2019)	
22	037232	Flat Neoprene Washer (2 required on units after 7/18/2019)	
23	037007	PCB Mounting Bracket (2 required on units after 7/18/2019)	
24	013768	Screw (2 required on units after 7/18/2019)	
25	Cord is Inclu	Cord is Included with Illustration# 8	
26	007556 012920 030618	Strain Relief (on units after 10/4/2019) Strain Relief (changed after 4/22/2014) Strain Relief (use 012920)	
27	013731	Cable Tie (3 required last used 5/31/2019)	
28	Bottom Hous	ing is Included with Illustration# 8	
29	012505	Screw (4 required)	
30	026430	Corner Post (4 required)	

Catalog MX1500XTPSEK

Model

MX1500XT22CK (on units after 6/26/2008)


MX1500XT22SEK

Waring/Factory Service Center 314 Ella T. Grasso Ave. Torrington, CT 06790 Tele. 1-800-269-6640

Fax 860-496-9017 www.waringcommercialproducts.com

Illustration#	Part#	Description
31	028928	Sems (4 required)
32	503397 503345	Blade Assembly (Raptor containers) Blade Assembly
33	024271	O Ring
34	024268	Nut Gasket
35	029631	Bearing Holder Nut


033484 Brush/Spring (2 required use with ECM motor)




Sound Enclosure Handle

Parts No Longer Used

(Last used on 4/27/2009)





037043 Sq. Drive Coupling 037041 Adapter **503601**

Sq. Drive Coupling with Adapter

503604

Sq. Drive Coupling with Adapter 2 Gen.