



Europe Drink Mixer 240 volt


PDM01E - white

PDM03E - yellow
(marked of deletion)


PDM04E - red
(marked of deletion)

PDM12E - retro green
(marked of deletion)

PDM21E - black



013653
Container



Catalog
PDM01E
PDM03E
PDM04E
PDM12E
PDM21E

Model

32DM33



Illustration #	Part #	Description
1	024192	Rocker Switch
2	018462	Screw 2 Req.'d
3	024290	Plated Upper Housing
4	028565 024191	Motor / with agitator (<i>current production</i>) Motor (<i>older units</i>)
5	018471 024195	Rubber Washer (<i>current production</i>) Rubber Washer (<i>older units</i>)
6	001843	Screw 3 Req.'d
7	024291	Plated Lower Housing
8	018714	Screw
9	018468	Cup Holder
10	019707 023048 023050 019695 023047	Base /black Base /chili red- <i>no longer available</i> Base /retro green Base /white Base /yellow- <i>no longer available</i>
11	019199	Cup Holder Stud
12	502752	EMI Filter Assy.
13	024284	Fuse
14	024287	Screw
15	024276	Fuse Block
16	024288	Washer
17	024289	Nut
18	019702	Lead /blue
19	502767	Lead Assy. /brown with 024300 insulating sleeve
20	012409	Crimp Connector 6 Req.'d
21	002943	Washer 2 Req.'d
22	013659	Sems 2 Req.'d
23	013731	Cable Tie 7 Req.'d
24	502763	Resistor Assy. / 026083 black lead, 025877 resistor, 025876 insulation sleeve
25	019694	Strain Relief

Catalog
PDM01E
PDM03E
PDM04E
PDM12E
PDM21E

Model

32DM33



Illustration #	Part #	Description
26	502546	Cord Set / white
	502547	Cord Set / black
27	502539	Bottom Plate Assy. w/EMI Filter & Fuse Block
	502534	Bottom Plate and Weight Assy.
28	018714	Screw 3 Req.'d
29	004090	Foot 3 Req.'d

