



CAUTION: DO NOT IMMERSE IN WATER.
WARNING: TO PREVENT ELECTRIC SHOCK, UNPLUG BEFORE CLEANING.
 SERIAL: WWYY

↑
 Date Code Location
 WWYY
 week week|year year



Europe 4 Slice Medium Duty Toaster WCT708E

Illustration#	Part#	Description
1	026990	Center Elements (2 required)
2	026991	Outer Elements (4 required)
3	026775	Carriage Control Lever Knob (2 required)
4	026774	Browning Control Knob (2 required)
5	026776	Crumb Tray (2 required)

